

This Page Is Inserted by IFW Operations  
and is not a part of the Official Record

## **BEST AVAILABLE IMAGES**

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

**IMAGES ARE BEST AVAILABLE COPY.**

**As rescanning documents *will not* correct images,  
please do not report the images to the  
Image Problem Mailbox.**




FIG. 1  
(PRIOR ART)




FIG. 2

20  
⚡




FIG. 3


Acct#12345

## THERMOSTAT - MANUAL

46  
⚡  
↓

Prepare for the upcoming season by reviewing your program needs.

Use the Thermostat - Schedule (clickable at left) to set your daily temperatures. If you would like to temporarily change these temperatures, use the thermostat below.



Click the up and down arrows until you reach the temperature you would like. This temperature will be set until the next schedule change. Check **HOLD** to maintain this setting across schedule changes.

You may also change the **MODE** and **FAN** settings.

**BE SURE TO CLICK SUBMIT WHEN DONE!!**

F.6.4